



# 4-Port

## 34W USB AC CHARGER

PCA-4U



## User Manual

### Product Features

---

1. Compact size, 4 dedicated USB ports with built-in 34W power, quite convenient for traveling.
2. 2x2.4A current charges 2 Tablet PCs/iPads and 2x1A current charges 2 smart phones, digital devices simultaneously.
3. AC input 100-240V, worldwide travel compatible, with exchangeable USA, Europe, UK, Australia, Korea or Chinese AC plugs.
4. Multiple safety protection functions: over current protection, over voltage protection, short circuit protection, over temperature protection.

## Product Specification

Model: PC-4U

Input: AC 100-240V 0.85A 50/60Hz

Output: USB 5V 1A\*2 & 5V 2.4A\*2 34W


Measurement: 96\*50.4\*38.6mm

Net Weight: 135g

Protection Function: OCP,OVP,SCP,OTP.

Quiescent Dissipation:  $\leq 0.3W$

## Product Diagram





CN



US



AU




UK

## Operation Instruction

---

1. Connect the PCA-4U to the power outlet using correct plug attachment.
2. Turn on the switch, and the LED indicator light up green.
3. Plug your device into the desired USB port and the PCA-4U will start to charge your device.
4. Once your devices is charged remove it from the PCA-4U.



## 2.4A:

---

Input Voltage	Output port	Output Voltage	Output Current	Fit for
AC 100-240V	1-2	5V	2.4A	For iPad, tablets etc.

## 1A:

Input Voltage	Output port	Output Voltage	Output Current	Fit for
AC 100-240V	1-2	5V	1A	For iPad,iPhone, Samsung, tablet and other smart phones etc

Notes: Maximum charging loading is 34W. Multiple products with total power consumption exceeds this limit can't be charged all simultaneously.



## Notes:

Please check that your devices charging specification should be in accordance to our manual instruction. Also read this manual carefully before use. We're not responsible for any damage caused by incorrect or reckless operation.

## Caution

---

1. Do not apply external force to the body of the PCA-4U.
2. Do not unplug by pulling the cord.
3. Do not place the PCA-4U near heating sources.
4. Do not bend the blade or Pins of the plug.
5. If there is any strange sound, smoke or odor, turn off at the switch immediately.
6. Do not disassemble (It may cause fire or electric shock)
7. Do not put any sharp objects into the venting hole of the product (It may cause fire or electric shock)
8. Ensure to plug in the product firmly.
9. Ensure not to use a damaged cable. (It may cause fire or electric shock)
10. While in use do not place the product on a bed, in bag or inside a closet, good ventilation is required.
11. Always wipe off the product with soft fabric cloth.
12. Keep the PCA-4U clean and free of dust (Dirt and dust may cause short circuit and fire)
13. Keep the PCA-4U out of reach of children.
14. Don't use the PCA-4U around wet areas. (It may cause electric shock)
15. Unplug the PCA-4U if you don't use the product for a long time. (It may cause heat, fire and electric shock)